






# Illustrated Parts List

EXPLODED VIEW – MAIN UNIT

MODELS 073011-0 & 073011-1



# Illustrated Parts List



## PARTS LIST – MAIN UNIT

### MODELS 073011-0 & 073011-1

Item	Part #	Description
1	865159GS	CRADLE
3	197755GS	VALVE, Check
4	197757GS	FLANGE, Inlet, 3" BSP
5	198057GS	ASSY, Plug
6	*	WASHER, Flat, 3/8 M10
7	*	HHCS, M10 - 1.5 x 20
8	*	HHCS, M10 - 1.5 x 25
9	*	WASHER, Lock M10
10	197753GS	HOUSING, Pump
11	197759GS	GASKET, Out
12	198155GS	ASSY, Plug
13	197761GS	FLANGE, Out, 3" BSP
14	197748GS	VOLUTE, 3"
15	198048GS	ASSY, Fastener
16	197739GS	ADAPTER, Engine
17	197765GS	GASKET, 3"
A	198062GS	ASSY, Housing Pump
B	198156GS	KIT, Impeller
C	197887GS	KIT, Vibration Mount
D	198157GS	KIT, Coupler, 3" BSP
E	198158GS	KIT, Seal

#### Parts Not Illustrated

MS5238	MANUAL, Operator's 073011
198302GS	DECAL, Recoil
198301GS	DECAL, Air Cleaner
198296GS	DECAL, Fuel Tank
198303GS	DECAL, Caution
198305GS	LABEL, Warning
§	ENGINE

**NOTE:** Item letters A - E are service kits and include all parts shown within the box.

§ - Contact Engine Manufacturer

Copyright © 2008 Briggs & Stratton Power Products Group, LLC. All rights reserved. No part of this material may be reproduced or transmitted in any form by any means without the express written permission of Briggs & Stratton Power Products Group, LLC.